

CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
	Spot		Job #	Revision 1B



GO CUBE Self Bunded Tank Operations Manual



Prepared by: Paul Morgan – Technical
Manager 3/8/2019

CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
			Job #	Revision 1B

Correct lifting of the GO CUBE



1. The GO CUBE range is fully rated and certified up to 6600L to be lifted and moved with fuel in the tank.
2. Only use the lifting points as identified on the GO CUBE
3. The GO CUBE is supplied standard with four way forklift pockets

Do not operate this equipment unless you are authorised and suitably trained.

1. Authorised persons are those that have been approved to use this equipment in the workplace and are suitably trained to do so.
2. All persons operating this equipment should do so in accordance with workplace health and safety and environmental guide lines governing their workplace.
3. Carry out pre-operational inspections prior to using this equipment.
4. Use personal protective equipment when operating this equipment.
5. Report all faults or potential hazards directly to the persons responsible in the workplace.
6. Upon finding any faults with the equipment do not operate the equipment, take the equipment out of service according to your workplace procedures and arrange for the equipment to be repaired by an authorised repairer.
7. GO offers training services where by GO provides suitably qualified persons to offer instruction on the safe use of the equipment provided.
8. GO offers service and repair to all refuelling equipment.



CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
	Spot		Job #	Revision 1B

The GO CUBE Self Bunded Tank range is designed and constructed in accordance with the following standards for the storage and transportation of fuel and oils compliant with

1. UN1202
2. UN31A/Y
3. AS1940 - 2017
4. AS1692

For location and installation of your GO CUBE refer to the Australian standards AS1940 and AS1692 storage of combustible and flammable liquids.

1. Seek approvals from governing bodies prior to installation, as required
2. Install appropriate signage, impact protection and fire fighting equipment suitable for the product stored and dispensed for the GO CUBE.
3. Install on a level hard compacted surface

GO Industrial offers services for installation and compliance with AS1940 and local governing authorities.



CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
	Spot		Job #	Revision 1B

The GO CUBE Self Bunded Tank range is clearly labeled with the following Decals:



1. Product label, Warning signage, Safe fill level, Fill point, Dip point, Suction point, Return point and Vent
2. Warning Only Lift When Empty
3. Warning No Welding or Drilling
4. Danger Confined Space
5. No Smoking No Naked Flame
6. Compliance plate and Serial Number are located under the lid
7. Instruction and Operations Guide is located under the lid

GO Industrial labelling is compliant with AS1940 and AS1692

Please ensure these decals are kept clean and are in good repair.

The GO CUBE is supplied with a tank gauge for content level; calibrated dip stick are not supplied as standard but are available from GO Industrial, a quote can be provided if required.



CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
	Spot		Job #	Revision 1B

Before filling the GO CUBE inspect the following:



1. Visible damage to the inner and outer tanks.
2. Labeling is correct for the product being stored in the GO CUBE.
3. Inspect for the correct operation of the vent.
4. Dip the tank prior to filling operations.
5. Pumping equipment, if fitted, is not in operation.
6. Ask you petroleum supplier to provide their site requirements prior to arranging a delivery.
7. No smoking, naked flames or hot works to be carried out in the refueling area
8. Only fill the GO CUBE with a hand held splash fill nozzle.
9. Do not leave unattended while filling.
10. Do not pressure fill the GO CUBE using a Camlock Fitting – Nozzle Fill Only
11. Do not overfill the GO CUBE.
12. Replace all caps upon completion of filling operations
13. Monitor the bunded area while filling



CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
	Spot		Job #	Revision 1B




Priming GO Supplied Pump

GO Industrial supplies and installs a wide variety of pumping equipment depending on the customer's requirements.

Please refer to the manufactures documents supplied for operation and service

1. Priming pump equipment, note most pumps supplied are self-priming and no further action is required. If required remove the hose from the suction point on top of the tank, fill suction hose with product. Reattach the hose and start the pump.
2. For centrifugal pumps remove the priming plug on the pump, fill with product. Replace the priming plug and start the pump.



CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
	Spot		Job #	Revision 1B

Normal Operation of the GO CUBE

The GO CUBE is designed to be fitted with pumping equipment and configured in multiple ways.

Common configurations are:

- Generator supply tank – no pumping equipment fitted
- Generator supply tank – pumping equipment fitted
- Light vehicle refuelling - hand operated pumping equipment
- Light vehicle refuelling powered equipment – 12Volt, 24Volt and 240Volt and Air Operated Pumping Equipment

GO recommends on site commissioning and training of the use and maintenance of the equipment

fitted. GO CUBE generic refueling operation procedure

1. Refer to the manufactures documentation for pumping equipment use and operation.
2. Inspect the GO CUBE and pumping equipment for damage and wear prior to operation and report any faults, do not operate if faults are found.
3. No Smoking or Naked Flames
4. Turn off vehicles prior to refueling
5. Wear PPE
6. Dip the GO CUBE prior to refueling operations to ensure sufficient product for the operation being carried out.
7. Remove the vehicle fuel cap, insert the refueling nozzle.
8. Start the pump and operate the nozzle, do not leave the nozzle unattended while refueling.
9. Upon completion of refueling operations turn off pumping equipment, replace hose and nozzle to avoid damage and trip hazards.
10. Replace vehicle filler cap.
11. Secure the GO CUBE in accordance with site procedures.



CUBE OPERATIONS MANUAL	Client	GO INDUSTRIAL	Title	GO CUBE Operations Manual
	Spot		Job #	Revision 1B

Scheduled Maintenance

GO Industrial recommends scheduled maintenance is carried out at set intervals 6 monthly by a suitably qualified tradesperson to any additional equipment fitted to the GO CUBE such as pumps, filters, meter calibrations and so on.

Check with GO Industrial regarding programmed maintenance for you CUBE Self Bunded Tank.

On a weekly basis check the following:

1. Check the GO CUBE for water contamination.
2. Check pumping equipment for wear and tear, refer to the manufactures documentation for pumping equipment use and operation
3. Inspect signage for damage to signage.
4. Monitor and clean bund.

GO can supply service, spare parts and accessories for your GO CUBE.

Contact GO Industrial on 07 3204 2240 or Contact Us

