

LineLazer™ V 200HS & 200DC Airless Line Stripers

Standard Series and High Production (HP) Series

3A3426H
EN

For the application of line striping materials.
For professional use only.
For outdoor use only.
Not for use in explosive atmospheres or hazardous locations.

Maximum Operating Pressure: 3300 psi (22.8 MPa, 228 bar)




Important Safety Instructions

Read all warnings and instructions in this manual and in related manuals before using the equipment.
 Be familiar with the controls and the proper usage of the equipment.
 Save these instructions.

| Related Manuals: | | | |
|------------------|-------|--------|----------------------------------|
| 3A3390 | Parts | 309277 | Pump |
| 311254 | Gun | 3A3428 | Auto-Layout Applications Methods |

LineLazer V 200HS
Standard Series



LineLazer V 200HS
High Production Series

LineLazer V 200DC

t28012C



Use only genuine Graco replacement parts.
 The use of non-Graco replacement parts may void warranty.

Contents

| | | | |
|--|-----------|---|-----------|
| Models | 3 | HP Auto Series and HP Reflective Series | 34 |
| Warnings | 4 | LineLazer V LiveLook Display | 35 |
| Important Laser Information for Units with Laser Option | 7 | HP Auto Series | 35 |
| Tip Selection | 8 | Initial Setup (HP Auto Series) | 36 |
| Component Identification (LLV 200HS) | 9 | Striping Mode (HP Auto Series) | 38 |
| Component Identification (LLV 200DC) | 10 | Measure Mode (HP Auto Series) | 39 |
| Grounding Procedure | | Layout Mode | 40 |
| (For Flammable Flushing Fluids Only) | 11 | Stall Calculator | 41 |
| Pressure Relief Procedure | 11 | Angle Calculator | 42 |
| Setup/Startup | 12 | Setup/Information | 44 |
| SwitchTip and Guard Assembly | 15 | Settings | 45 |
| Gun Placement | 16 | Information | 46 |
| Install Guns | 16 | Data Logging | 48 |
| Position Gun | 16 | Maintenance | 49 |
| Select Guns (Standard Series) | 16 | Recycling and Disposal | 50 |
| Select Guns (HP Auto Series) | 17 | Rechargeable Battery Disposal | 50 |
| Gun Positions Chart | 18 | End of Product Life | 50 |
| Gun Arm Mounts | 19 | Troubleshooting | 51 |
| Change Gun Position (Front and Back) | 19 | Hydraulic Oil/Filter Change | 56 |
| Change Gun Position (Left and Right) | 19 | Removal | 56 |
| Installation | 20 | Installation | 56 |
| Trigger Sensor Adjustment | 20 | Wiring Diagram 200HS (Standard Series) | 57 |
| Gun Cable Adjustment | 21 | Wiring Diagram 200HS (HP Auto Series/HP Reflective Series) | 58 |
| Straight Line Adjustment | 22 | Wiring Diagram 200DC (Standard Series) | 59 |
| Handle Bar Adjustment | 22 | Wiring Diagram 200DC (HP Auto Series/HP Reflective Series) | 60 |
| Dot Laser (if applicable) | 23 | World Symbol Key | 61 |
| Cleanup | 24 | Technical Specifications | 62 |
| LineLazer V LiveLook Display | 26 | CALIFORNIA PROPOSITION 65 | 68 |
| Standard Series | 26 | Graco Standard Warranty | 69 |
| Initial Setup (Standard Series) | 27 | Graco Information | 70 |
| Striping Mode (Standard Series) | 29 | | |
| Measure Mode (Standard Series) | 30 | | |
| Setup/Information | 31 | | |
| Settings | 32 | | |
| Information | 33 | | |

Models

| LineLazer V 200HS & 200DC | | | | | | | | | | | |
|---------------------------|--------|--------|--------------------------|---------------------------|-----------------------|---------------------------------------|------------------------|---|---|--|--|
| | Model: | Series | Standard 1 Manual Gun | Standard 2 Manual Guns | HP Auto 1 Auto Gun | HP Auto 1 Manual Gun 1 Auto Gun | HP Auto 2 Auto Guns | HP Reflective 1 Manual Gun 1 PBS Tank | HP Reflective 1 Auto Gun 1 PBS Tank | HP Reflective 2 Auto Guns 1 PBS Tank | HP Reflective 2 Manual Guns 1 PBS Tank |
| 200HS | 17H459 | B | ✓ CE | | | | | | | | |
| | 17H461 | B | | ✓ CE | | | | | | | |
| | 17K582 | B | | | ✓ CE | | | | | | |
| | 17H462 | B | | | ✓ with laser | | | | | | |
| | 17K637 | B | | | | ✓ CE | | | | | |
| | 17H463 | B | | | | ✓ with laser | | | | | |
| | 17K583 | B | | | | | ✓ CE | | | | |
| | 17H464 | B | | | | | ✓ with laser | | | | |
| | 17H460 | B | | | | | | ✓ CE | | | |
| | 17J964 | B | | | | | | | ✓ CE | | |
| | 17K585 | B | | | | | | | | ✓ CE | |
| | 17H465 | B | | | | | | | | ✓ with laser | |
| 200DC | 17Y269 | A | | | | | ✓ with laser | | | | |
| | 17Y270 | A | | | | | | | | ✓ with laser | |
| | 17Y231 | A | | ✓ CE | | | | | | | |
| | 17Y232 | A | | | | | ✓ CE | | | | |
| | 17Y233 | A | | | | | | | | ✓ CE | |
| | 17Y648 | A | | | | | | | | | ✓ CE |

* All auto guns can be actuated manually.

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

WARNING



FIRE AND EXPLOSION HAZARD

Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:



- Use equipment only in well ventilated area.
- Do not fill fuel tank while engine is running or hot; shut off engine and let it cool. Fuel is flammable and can ignite or explode if spilled on hot surface.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).
- Ground all equipment in the work area. See **Grounding** instructions.
- Never spray or flush solvent at high pressure.
- Keep work area free of debris, including solvent, rags and gasoline.
- Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
- Use only grounded hoses.
- Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are antistatic or conductive.
- **Stop operation immediately** if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem.
- Keep a working fire extinguisher in the work area.



SKIN INJECTION HAZARD








High-pressure spray is able to inject toxins into the body and cause serious bodily injury. In the event that injection occurs, **get immediate surgical treatment**.



- Do not aim the gun at, or spray any person or animal.
- Keep hands and other body parts away from the discharge. For example, do not try to stop leaks with any part of the body.
- Always use the nozzle tip guard. Do not spray without nozzle tip guard in place.
- Use Graco nozzle tips.
- Use caution when cleaning and changing nozzle tips. In the case where the nozzle tip clogs while spraying, follow the **Pressure Relief Procedure** for turning off the unit and relieving the pressure before removing the nozzle tip to clean.
- Equipment maintains pressure after power is shut off. Do not leave the equipment energized or under pressure while unattended. Follow the **Pressure Relief Procedure** when the equipment is unattended or not in use, and before servicing, cleaning, or removing parts.
- Check hoses and parts for signs of damage. Replace any damaged hoses or parts.
- This system is capable of producing 3300 psi. Use Graco replacement parts or accessories that are rated a minimum of 3300 psi.
- Always engage the trigger lock when not spraying. Verify the trigger lock is functioning properly.
- Verify that all connections are secure before operating the unit.
- Know how to stop the unit and bleed pressure quickly. Be thoroughly familiar with the controls.



WARNING

| | |
|---|--|
|  | <p>CARBON MONOXIDE HAZARD Exhaust contains poisonous carbon monoxide, which is colorless and odorless. Breathing carbon monoxide can cause death.</p> <ul style="list-style-type: none"> Do not operate in an enclosed area. |
|   | <p>EQUIPMENT MISUSE HAZARD Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> Do not operate the unit when fatigued or under the influence of drugs or alcohol. Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See Technical Data in all equipment manuals. Use fluids and solvents that are compatible with equipment wetted parts. See Technical Data in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request Safety Data Sheets (SDSs) from distributor or retailer. Do not leave the work area while equipment is energized or under pressure. Turn off all equipment and follow the Pressure Relief Procedure when equipment is not in use. Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only. Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards. Make sure all equipment is rated and approved for the environment in which you are using it. Use equipment only for its intended purpose. Call your distributor for information. Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not kink or over bend hoses or use hoses to pull equipment. Keep children and animals away from work area. Comply with all applicable safety regulations. |
|  | <p>PRESSURIZED ALUMINUM PARTS HAZARD Use of fluids that are incompatible with aluminum in pressurized equipment can cause serious chemical reaction and equipment rupture. Failure to follow this warning can result in death, serious injury, or property damage.</p> <ul style="list-style-type: none"> Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents. Do not use chlorine bleach. Many other fluids may contain chemicals that can react with aluminum. Contact your material supplier for compatibility. |
|   | <p>MOVING PARTS HAZARD Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> Keep clear of moving parts. Do not operate equipment with protective guards or covers removed. Equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure and disconnect all power sources. |
|  | <p>ENTANGLEMENT HAZARD Rotating parts can cause serious injury</p> <ul style="list-style-type: none"> Keep clear of moving parts. Do not operate equipment with protective guards or covers removed. Do not wear loose clothing, jewelry or long hair while operating equipment. Equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure and disconnect all power sources. |



WARNING

**TOXIC FLUID OR FUMES HAZARD**

Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.

- Read Safety Data Sheets (SDSs) to know the specific hazards of the fluids you are using.
- Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.

**BURN HAZARD**

Equipment surfaces and fluid that's heated can become very hot during operation. To avoid severe burns:

- Do not touch hot fluid or equipment.

**PERSONAL PROTECTIVE EQUIPMENT**

Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This protective equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.

**BATTERY HAZARD**

The battery may leak, explode, cause burns, or cause an explosion if mishandled. Contents of an open battery can cause severe irritation and/or chemical burns. If on skin, wash with soap and water. If in eyes, flush with water for at least 15 minutes and get immediate medical attention.



- Only use the battery type specified for use with the equipment. See **Technical Data**.
- Replace battery only in well-ventilated area and away from flammable or combustible materials, including paints and solvents.
- Do not dispose of battery in fire or heat above 50°C (122°F). The battery is capable of exploding.
- Do not throw into fire.
- Do not expose battery to water or rain.
- Do not disassemble, crush, or penetrate the battery.
- Do not use or charge a battery that is cracked or damaged.
- Follow local ordinances and/or regulations for disposal.

**ELECTRIC SHOCK HAZARD**

Hazardous voltage is present in control box while engine is running.

- Turn off engine before servicing equipment.

Important Laser Information for Units with Laser Option

WARNING



LASER LIGHT HAZARD: AVOID DIRECT EYE CONTACT

Eye exposure to Class IIIa3/3R levels of laser light can potentially present an eye (retinal) injury hazard, including spot blindness or other retinal injury. To avoid direct eye exposure:

- Never look directly in to a laser beam or point the beam into the eyes of others, even at long distances.
- Never shine the laser at mirror like surfaces which can cause specular reflections of the beam.
- Always set the laser at a height and angle that prevents the beam from shining into people's eyes.
- Immediately terminate laser emissions if personnel, animals or reflective objects approach the beam.
- Always turn off laser when unattended.
- Do not remove any warning labels from the laser.
- Only properly trained laser operators are to use this product.
- Never allow beams to be aimed toward traffic, vehicles, or heavy equipment. Even when not damaging at long distances, the high brightness of lasers can distract or disrupt vehicle operations.
- Never point a laser at an aircraft or law enforcement personnel. This is considered a felony in most locations, with the possibility of jail time, heavy fines or both.
- Do not disassemble laser product. Return to factory for all service procedures.
- Laser must be turned OFF when cleaning the lens, so as not to create unwanted laser refraction.



LASER RADIATION HAZARD

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

- Do not attempt to open or disassemble the laser housing under any circumstances. Doing so may cause exposure to potentially hazardous levels of laser radiation.
- No serviceable parts within. Unit is factory sealed.











FIRE AND EXPLOSION HAZARD

Connecting directly to a generator source can create a short or sparking under certain conditions.


- Only connect GL1700 to a dedicated 12 volt DC battery source.

Tip Selection


|  1127606a |  1127505a in. (cm) |  1127506a in. (cm) |  1127507a in. (cm) |  1127508a in. (cm) |  1127509a |  1127510a |  1127605a |
|---|--|--|--|--|--|---|---|
| LL5213* | 2 (5) | | | | ✓ | | |
| LL5215* | 2 (5) | | | | | ✓ | |
| LL5217 | | 4 (10) | | | | ✓ | |
| LL5219 | | 4 (10) | | | | | ✓ |
| LL5315 | | 4 (10) | | | ✓ | | |
| LL5317 | | 4 (10) | | | ✓ | | |
| LL5319 | | 4 (10) | | | | ✓ | |
| LL5321 | | 4 (10) | | | | ✓ | |
| LL5323 | | 4 (10) | | | | ✓ | |
| LL5325 | | 4 (10) | | | | | ✓ |
| LL5327 | | 4 (10) | | | | | ✓ |
| LL5329 | | 4 (10) | | | | | ✓ |
| LL5331 | | 4 (10) | | | | | ✓ |
| LL5333 | | 4 (10) | | | | | ✓ |
| LL5335 | | 4 (10) | | | | | ✓ |
| LL5355 | | 4 (10) | | | | | ✓ |
| LL5417 | | | 6 (15) | | ✓ | | |
| LL5419 | | | 6 (15) | | ✓ | | |
| LL5421 | | | 6 (15) | | ✓ | | |
| LL5423 | | | 6 (15) | | | ✓ | |
| LL5425 | | | 6 (15) | | | ✓ | |
| LL5427 | | | 6 (15) | | | ✓ | |
| LL5429 | | | 6 (15) | | | ✓ | |
| LL5431 | | | 6 (15) | | | | ✓ |
| LL5435 | | | 6 (15) | | | | ✓ |
| LL5621 | | | | 12 (30) | ✓ | | |
| LL5623 | | | | 12 (30) | ✓ | | |
| LL5625 | | | | 12 (30) | ✓ | | |
| LL5627 | | | | 12 (30) | ✓ | | |
| LL5629 | | | | 12 (30) | ✓ | | |
| LL5631 | | | | 12 (30) | | ✓ | |
| LL5635 | | | | 12 (30) | | ✓ | |
| LL5639 | | | | 12 (30) | | | ✓ |

*Use 100 mesh filter to reduce tip clogs.

Component Identification (LLV 200HS)



t128030a




| | |
|---|--------------------------|
| 1 | Display |
| 2 | Manual Spray Gun Trigger |
| 3 | Prime/Spray Valve |
| 4 | Filter |
| 5 | Trigger Lock |
| 6 | Engine/Controls |
| 7 | Drain and Siphon Tubes |
| 8 | Pump ON/OFF Lever |
| 9 | Pressure Control |


| | |
|-----|-------------------------------|
| 10 | Turn Control |
| 11 | Engine STOP |
| *12 | 12 Volt Battery |
| *13 | Gun Actuators / Solenoids |
| *14 | Layout Laser |
| 15 | Engine Kill Switch |
| 16 | Identification Label |
| *17 | Auto Spray Gun Control Button |

*HP Auto Series only.

Component Identification (LLV 200DC)



ti35421a



| | |
|---|--------------------------|
| 1 | Display |
| 2 | Manual Spray Gun Trigger |
| 3 | Prime/Spray Valve |
| 4 | Filter |
| 5 | Trigger Lock |
| 6 | Engine/Controls |
| 7 | Drain and siphon tubes |
| 8 | Pump ON/OFF lever |
| 9 | Pressure control |

| | |
|-----|-------------------------------|
| 10 | Turn control |
| 11 | Engine STOP |
| *12 | 12 volt battery |
| *13 | Gun Actuators / Solenoids |
| *14 | Layout laser |
| 15 | Engine kill switch |
| 16 | Identification label |
| *17 | Auto Spray Gun Control Button |


*HP Auto Series only.

Grounding Procedure (For Flammable Flushing Fluids Only)

| | | | | |
|--|--|--|--|--|
| | | | | |
|--|--|--|--|--|

This equipment must be grounded to reduce the risk of static sparking. Static sparking can cause fumes to ignite or explode. Grounding provides an escape wire for the electric current.

1. Position striper so that the tires are not on pavement.
2. Striper is shipped with a grounding clamp. Grounding clamp must attach to grounded object (e.g. metal sign post).




3. Disconnect grounding clamp after flushing is complete.

Pressure Relief Procedure


| | | | | |
|--|--|--|--|--|
| | | | | |
| | | | | |

This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing the equipment.


1. Perform **Grounding Procedure (For Flammable Flushing Fluids Only)**, page 11.
2. Set pump switch to **OFF**. Turn engine **OFF**.



3. Turn pressure control to lowest setting. Trigger all guns to relieve pressure.




4. Engage all gun trigger locks. Turn prime valve down.




5. If you suspect the spray tip or hose is clogged or that pressure has not been fully relieved:
 - a. **VERY SLOWLY** loosen the tip guard retaining nut or the hose end coupling to relieve pressure gradually.
 - b. Loosen the nut or coupling completely.
 - c. Clear the obstruction in the hose or tip.

Setup/Startup




This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing the equipment.

1. Perform **Pressure Relief Procedure**, page 11.
2. Perform **Grounding Procedure (For Flammable Flushing Fluids Only)**, page 11, if using flammable materials.
3. Fill throat packing nut with Throat Seal Liquid (TSL) to decrease packing wear. Both for 200DC.




4. Check engine oil level. Add SAE 10W-30 (summer) or 5W-30 (winter). See engine manual.




5. Fill fuel tank.


6. Set pump switch to **OFF**. Both for 200DC



7. If removed, install strainer. Both for 200DC




8. Turn prime valve down (both for 200DC). Turn pressure control counterclockwise to lowest pressure.




NOTE: Minimum hose size allowable for proper sprayer operation is one 3/8 in. x 22 ft for LL200HS, or two 3/8 in. x 11' 10" for LL200DC.

9. Place siphon tube set in grounded metal pail partially filled with flushing fluid. Attach ground wire to true earth ground. Use water to flush water-base paint and mineral spirits to flush oil-base paint and storage oil. For 200DC, perform this step for first color/pump to be primed.




10. Start engine:


a. Move fuel valve to open.




b. Move choke to closed.




c. Set throttle to fast.




d. Set engine switch to ON.




e. Pull starter cord.




11. After engine starts, move choke to open.




12. Set throttle to desired setting.




13. Digital display is functional after engine starts.




14. Set pump switch to **ON** (pump is now active). For 200DC, perform this step for first color/pump to be primed.




15. Increase pressure control enough to start pump. Allow fluid to circulate for 15 seconds.



16. Turn pressure down, turn prime valve horizontal. Disengage gun trigger lock.




17. Hold all guns against a grounded metal flushing pail. Trigger guns and increase fluid pressure slowly until pumps run smoothly.




High-pressure spray is able to inject toxins into the body and cause serious bodily injury. Do not stop leaks with hand or rag.

18. Inspect fittings for leaks. If leaks occur, turn sprayer OFF immediately. Perform **Pressure Relief Procedure**. Tighten leaky fittings. Repeat **Startup**, steps 1 - 17. If no leaks, continue to trigger gun until system is thoroughly flushed. Proceed to step 19.

19. Place siphon tube in paint pail.



20. Trigger all guns again into a flushing fluid pail until paint appears. Assemble tips and guards.




21. For 200DC, repeat steps 8-9, and 14-20 for second color/pump to be primed.

SwitchTip and Guard Assembly




To avoid serious injury from skin injection do not put your hand in front of the spray tip when installing or removing the spray tip and tip guard.

1. Engage trigger lock. Use end of SwitchTip to press OneSeal into tip guard, with curve matching tip bore.




2. Insert SwitchTip in tip bore and firmly thread assembly onto gun.



Gun Placement


Install Guns

1. Insert guns into gun holder. Tighten clamps.




Position Gun


2. Position gun: up/down, forward/reverse, left/right. See **Gun Positions Chart**, page 18, for examples.



NOTE: When striping above a curb, the mounting clamp can be rotated for clearance.




Another option can be to swing the gun out at an angle and rotate the tip guard. This results in better visibility for the user.



Select Guns (Standard Series)

3. Connect gun cables to left or right gun selector plates.



- a. One gun: Disconnect one gun selector plate from trigger.



- b. Both guns simultaneously: Adjust both gun selector plates to the same position.




- c. Solid-skip and skip-solid: Adjust solid-line gun to position 1 and skip-line to position 2.




Select Guns (HP Auto Series)


1. Use the gun selector buttons to determine which guns are active. Each gun selector has 3 settings: continuous line, OFF and programmed line pattern.




2. Use the auto gun trigger control to actuate guns.



4 Examples:




Gun Positions Chart



| | |
|---|---|
| 1 | One line |
| 2 | One line up to 24 in. (61cm) wide |
| 3 | Two lines |
| 4 | One line or two lines to spray around obstacles |
| 5 | One gun curb |
| 6 | Two gun curb |
| 7 | Two lines or one line up to 24 in. (61 cm) wide |


Gun Arm Mounts

This unit is equipped with front and rear gun arm mounts.




Change Gun Position (Front and Back)


1. Loosen gun arm knob and remove from gun arm mounting slot.




2. Slide gun arm assembly (including gun and hoses) out from gun arm mounting slot.



3. Slide gun arm assembly into desired gun arm mounting slot.



4. Tighten gun arm knob into gun arm mounting slot.





NOTICE

Make sure all hoses, cables, and wires are properly routed through brackets and do NOT rub on tire. Contact with tire will result in damaged hoses, cables, and wires.


Change Gun Position (Left and Right)

Removal

1. Loosen vertical gun arm knob on gun arm mounting bar and remove.




2. Extend mounting bar on opposite side of the machine.



Installation


1. Install vertical gun mount onto gun bar.



NOTE: Make sure all hoses, cables, and wires are properly routed through brackets.


No fluid spray

2. Turn screw in handle clockwise if spray icon appears before fluid spray starts.




No spray icon

3. Turn screw in handle counterclockwise if fluid spray starts before spray icon appears.




Trigger Sensor Adjustment

1. Start striper engine. Pull trigger. Spray icon should appear simultaneously with start of fluid spray.




4. Continue adjusting screw in trigger until timing of spray icon and fluid spray are synchronized.



Gun Cable Adjustment


Adjusting the gun cable will increase or decrease the gap between the trigger plate and the gun trigger. To adjust trigger gap, perform the steps below.



Standard Series


ti27884a

HP Auto Series
(has 2 locations)



ti27885b

1. Use wrench to loosen locking nut on cable adjuster.




ti27804a

2. Loosen or tighten adjuster until desired result is achieved. **NOTE:** More thread exposed means less gap between gun trigger and trigger plate.
3. Use wrench to tighten locking nut on the adjuster.

Adding Gun Cable (HP Auto Series)


The HP Auto Series can be equipped with two gun actuators. Each gun actuator is capable of operating one cable.

1. Select cable end with adjuster.
2. Install exposed cable through cable bracket slot.




ti27805b

3. Insert plastic cable retainer into cable bracket hole.




ti27806b

4. Install cable end onto trigger plate pin and install clip.




ti27807b

5. Route cable around unit and up through cable holes behind hose mount.



ti27808a

6. Route cable end loop through rectangular hole in bracket and insert plastic cable retainer into the actuator bracket. Install cable end onto actuator rod and install pin.




ti27809a


Straight Line Adjustment

The front wheel is set to center the unit and allow the operator to form straight lines. Over time, the wheel may become misaligned and will need to be readjusted. To re-center the front wheel, perform the following steps:


1. Loosen bolt on the front wheel bracket.




2. If striper arcs to the right, loosen left set screw and tighten right set screw for fine tune adjustment.




3. If striper arcs to the left, loosen right set screw and tighten left set screw.




4. Roll the striper. Repeat steps 2 and 3 until striper rolls straight. Tighten bolt on wheel alignment plate to lock the new wheel setting.




Handle Bar Adjustment




Dot Laser (if applicable)




1. Remove battery cover.




2. Attach ON/OFF switch to desired location on the handle bar.




3. Attach laser to desired location on the gun arm.




4. Route wires from the switch to the battery and connect to the (+) and (-) terminals.




5. Connect the switch leads to the wire harness.




6. Reattach battery cover.



7. Turn on laser and position dot underneath gun head.




Cleanup




This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing the equipment.


1. Perform **Pressure Relief Procedure**, page 11.
2. Remove guard and SwitchTip from all guns.




3. Unscrew cap, remove filter. Assemble without filter. Both for 200DC.



4. Clean filter, guard and SwitchTip in flushing fluid.



5. Place siphon tube set in grounded metal pail partially filled with flushing fluid. Attach ground wire to true earth ground. Perform **Startup** steps 10 - 17 (see page 13) to flush out paint in sprayer. Use water to flush water-base paint and mineral spirits solvent (also called white spirit) to flush oil-base paint. Perform this step for both pumps for 200DC sprayers.
6. Hold gun against paint bucket and pull trigger until water or solvent appears. Repeat for additional guns.



7. Move gun to solvent or water bucket. Hold gun against bucket and pull trigger until the system is thoroughly flushed. Repeat for additional guns.
8. Fill pump with Pump Armor, perform **Pressure Relief Procedure**, page 11, then reassemble filter, guard, and SwitchTip.
9. Each time you spray and store, fill throat packing nut with TSL to decrease packing wear.