

## Stencil Kit for Electric Turf Striper

332461A  
EN


*- For turf striping applications only -*

### Model 24R236



#### IMPORTANT SAFETY INSTRUCTIONS

Read all warnings and instructions in this manual and in the Electric Turf Striper manual. Save these instructions.



## **WARNING**






#### FIRE AND EXPLOSION HAZARD

Solvent and paint fumes can ignite or explode.


- Use only water-based materials.
- Do not spray or flush with flammable materials.



# Pressure Relief Procedure


			
<p>Do not operate or spray near children. Do not aim the material dispenser at, or spray any person or animal. Keep hands and other body parts away from the discharge. For example, do not try to stop the paint flow with any part of the body.</p> <p>This striper builds up an internal pressure of 1200 psi (8.3 MPa, 83 bar) during use. Follow this <b>Pressure Relief Procedure</b> whenever you stop spraying and before cleaning, checking, servicing, or transporting equipment to prevent serious injury.</p>			

1. Put prime/spray valve UP to release pressure.




## Installation Instructions


1. Empty material hopper.




2. Remove existing hose from material dispenser and pump outlet.




3. Connect plug end of stencil kit to pump outlet.




4. Connect stencil kit plug to spray button plug on striper.



5. Connect spray button cord to "Y" connection on stencil kit.




6. Connect other end of stencil kit to material dispenser.




## Operation

1. Remove material dispenser from vertical arm mount. Hold material dispenser in one hand and use other hand to operate the spray switch.



2. When finished with stencil, wrap hose around top of hopper and attach material dispenser to vertical arm mount.



## Shutdown and Cleaning

See striper manual for **Shutdown and Cleaning** instructions.

*All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice. For patent information, see [www.graco.com/patents](http://www.graco.com/patents). Original instructions. This manual contains English. MM 332461*

**Graco Headquarters:** Minneapolis  
**International Offices:** Belgium, China, Japan, Korea  
**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**  
 Copyright 2012, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.  
[www.graco.com](http://www.graco.com)  
 Revision A - April 2013

