

PRODUCT INFORMATION

How to extend the life of your Ratchet Jack Stand

10 Top Tips

to extend the life of your TradeQuip Ratchet Jack Stand

Includes Models: 1128T, 1148T, 1162T

1 At assembly and prior to use, the Ratchet Locking Tab or Bolt must be secured.

Secure the ratchet bar into the frame by bending the locking tab inwards using a hammer and punch on the 1128T/1148T or tighten the bolt on the 1162T. This will help prevent inadvertent separation of the ratchet bar from the base frame during vehicle support setup.

1128T/1148T 1162T



6 Correct Placement.

Vehicle Stands should always have the load cradle centrally positioned on the vehicle lift points. Consult the vehicle manufacturer for lifting and vehicle stand loading points prior to elevating or supporting a vehicle.

Vehicle loading points must remain within the cradle support area



2 Regularly lubricate ratchet mechanism including, pivot points, ratchet teeth and ratchet pawl.

Lubrication of all pivot points, ratchet teeth and ratchet pawl to ensure smooth operation while adjusting to the height clearances of a raised vehicle and provides a positive locking of the mechanism when under load. We recommend a light weight general purpose spray grease.



3 TradeQuip 2- and 4-ton stands come with a secondary locking device.

Once the correct height is set insert the locking pin prior to lowering a vehicle onto the stand.



4 TradeQuip Ratchet Jack Stands must be used on a smooth horizontal surface.

Ratchet Jack Stands rely on a smooth flat horizontal surface to remain stable and minimise lateral forces. When raising a vehicle from an axle to place on stands the correct balance point must be used to prevent tipping or load collapse.



5 Securing the Vehicle.

A vehicle must have the park brake applied and the wheels chocked prior to raising to place a vehicle stand. Vehicle stands can only be used to support one end of a vehicle. The stability of a vehicle on stands is critical to the safety of personnel conducting repairs.



7 Garage Jacks are NOT substitutes for Vehicle Stands.

Jacks must be used only to raise a vehicle for the purpose of lowering on to Vehicle Stands prior to commencement of vehicle maintenance.



8 Personal Safety.

No persons should be in a vehicle that is supported by Vehicle Stands. Engine must be turned off. Testing of Drivetrain or running of Engines whilst a vehicle is on stands can create vibration and potential tipping of the vehicle.

9 Read the user Manual thoroughly and keep a copy easily accessible.

Manuals are important to the initial set up and ongoing maintenance and come with each Vehicle Stand pair, they are also downloadable from our webpage at www.tqbbrands.com.au

10 Visit our webpage for instructional Videos.

We have created instructional videos for our range of Vehicle Stands including maintenance, and product comparisons. You'll find these at www.tqbbrands.com.au