

EVO™ 200 AND EVO™ 400 COVER

REPLACEMENT GUIDE

The information in this publication is provided for reference only. While every effort has been made to ensure the reliability and accuracy of the information contained in this manual at the time of printing, we recommend that you refer to “franklinfueling.com” for the most current version of this manual. All product specifications, as well as the information contained in this publication, are subject to change without notice. Franklin Fueling Systems does not assume responsibility and expressly disclaims liability for loss, damage, or expense arising out of, or in any way connected with, installation, operation, use, or maintenance by using this manual. Franklin Fueling Systems assumes no responsibility for any infringement of patents or other rights of third parties that may result from use of this manual or the products. We make no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Copyright © 2019 Franklin Fueling Systems, LLC, Madison, WI 53718. All world rights reserved. No part of this publication may be stored in a retrieval system, transmitted, or reproduced in any way, including, but not limited to, photocopy, photograph, magnetic, or other record, without the prior written permission of Franklin Fueling Systems.

For technical assistance, please contact:

Franklin Fueling Systems
3760 Marsh Rd.
Madison, WI 53718
USA

franklinfueling.com
3760 Marsh Rd. • Madison, WI 53718, USA
Tel: +1 608 838 8786 • Fax: +1 608 838 6433
Tel: USA & Canada +1 800 225 9787 • Tel: UK +44 (0) 1473 243300
Tel: Mex 001 800 738 7610 • Tel: DE +49 6571 105 308 • Tel: CN +86 10 8565 4566

EVO is a trademark of Franklin Electric Company

228180037 r1

goind.com.au

Contents

Introduction	1
Questions and concerns	1
Conventions used in this manual	1
Operating precautions	2
Replacing the Cover	3





Introduction

This manual contains instructions for replacing the cover on the Franklin Fueling Systems (FFS) EVO™ 200 and EVO™ 400 Automatic Tank Gauges (ATGs). You must follow all safety information, warnings, instructions, and other information in this manual. Please read this entire manual carefully. If you do not follow the instructions in this manual, the result could be faulty operation, equipment damage, injury, or death.

Questions and concerns

In case of emergency, follow the procedures established by your facility. If you have questions or concerns about safety or need assistance, use the information below to contact FFS:

franklinfueling.com

3760 Marsh Rd. • Madison, WI 53718, USA

Tel: +1 608 838 8786 • Fax: +1 608 838 6433

Tel: USA & Canada +1 800 225 9787 • Tel: UK +44 (0) 1473 243300

Tel: Mex 001 800 738 7610 • Tel: DE +49 6571 105 308 • Tel: CN +86 10 8565 4566

Conventions used in this manual

This manual includes safety precautions and other important information presented in the following format:

NOTE: This provides helpful supplementary information.

IMPORTANT: This provides instructions to avoid damaging hardware or a potential hazard to the environment, for example: fuel leakage from equipment that could harm the environment.

⚠ CAUTION: This indicates a potentially hazardous situation that could result in minor or moderate injury if not avoided. This may also be used to alert against unsafe practices.

⚠ WARNING: This indicates a potentially hazardous situation that could result in severe injury or death if not avoided.

⚠ DANGER: This indicates an imminently hazardous situation that will result in death if not avoided.

Operating precautions

FFS equipment is designed to be installed in areas where volatile liquids such as gasoline and diesel fuel are present. Working in such a hazardous environment presents a risk of severe injury or death if you do not follow standard industry practices and the instructions in this manual. Before you work with or install the equipment covered in this manual, or any related equipment, read this entire manual, particularly the following precautions:

⚠ CAUTION: Use only original FFS parts. Substituting non-FFS parts could cause the device to fail, which could create a hazardous condition and/or harm the environment.

⚠ WARNING: Follow all codes that govern how you install and service this product and the entire system. Always lock out and tag electrical circuit breakers while installing or servicing this equipment and related equipment. A potentially lethal electrical shock hazard and the possibility of an explosion or fire from a spark can result if the electrical circuit breakers are accidentally turned on while you are installing or servicing this product. Refer to this manual (and documentation for related equipment) for complete installation and safety information.

⚠ WARNING: Follow all federal, state, and local laws governing the installation of this product and its associated systems. When no other regulations apply, follow NFPA codes 30, 30A, and 70 from the National Fire Protection Association. Failure to follow these codes could result in severe injury, death, serious property damage, and/or environmental contamination.

⚠ WARNING: All wiring must enter the console's enclosure through the designated knockouts. An explosion hazard may result if other openings are used. All wiring from probes to the console must be run in conduit separate from all other wiring. Failure to do so will create an explosion hazard.

⚠ DANGER: Make sure you check the installation location for potential ignition sources such as flames, sparks, radio waves, ionizing radiation, and ultrasound sonic waves. If you identify any potential ignition sources, you must make sure safety measure are implemented.

goind.com

Replacing the Cover

NOTE: If you are upgrading your EVO™ 200 or EVO™ 400 ATG to have an LCD display, you will receive a new cover that has an opening for the display.

IMPORTANT: Make sure you wear a grounding strap during this procedure. If you do not, your EVO™ 200 or EVO™ 400 ATG could be permanently, severely damaged, and your warranty could be voided.

IMPORTANT: Lift the cover away carefully to help avoid damaging the LED light pipes.

⚠ WARNING: Your ATG has more than one power connection point. To avoid equipment damage and a shock hazard, make sure all power connection points to the ATG are disconnected before you begin servicing your ATG. Also, always perform a proper lockout/tagout (LOTO) procedure to prevent accidental energization of your ATG while you are servicing it.

1. Press the cover release tabs inward, and then lift the cover straight away from the ATG with both hands.



IMPORTANT: In the following step, be careful when you lower the cover onto the ATG in order to avoid damaging the LED light pipes.

2. Lower the cover straight onto the ATG so that the LED light pipes are not bent or broken. Lower the cover until the release tabs click into their holes in the sides of the ATG.
3. Turn on the circuit breaker for the ATG.



goind.com.au